


FRIGGA

Frigga A90 (Single-use)



Appearance Instruction



Note: The AC code (Activation code) is in the back of device.

Instructions

In order to better experience the real-time monitoring (temperature, location, track routes), real-time alarm (SMS, email) of Frigga wireless temperature recorder, it is recommended to register your business account on Frigga cloud platform official website (cloud.friggatech.com) and then add the device ID to your account before starting the device.



1. Start:

Long press “Start/Stop” button till blue indicator LED flash, the device is ready. Start delay is 30 min. (In this stage blue led will flash every 10 sec.), after delay time, the LED stop and the device start to record the temperature data.

(Using default thresholds or change the thresholds via Frigga cloud platform).

Usage method is same as traditional USB logger.

2. Setting:

Thresholds can be changed via cloud platform.

On the page “Device Setting”, we can:

- Change the temperature thresholds.
- Add alarm notification personnel.
- Share equipment to someone.
- Setting position notification.
- Set up automatic flight mode.



3. Transport:

Put the device into the goods and begin to transport.



4. Monitoring:

Whether you set up the device or not, you also can monitor the temperature, humidity, location, route through Frigga cloud platform.

- When the temperature is over limit, the cloud platform will notify the relevant person by mail or SMS.
- Notify the presupposed person when the device reaches the designated location.
- When the device arrives near the designated airport, the device will enter the flight mode automatically.



5. Stop:

Three ways to end journey:

- ① Long press “Start/Stop” button till Red indicator LED flash, the device is ending.
- ② Tear open the wrapping, plug in the logger into PC.
- ③ Via cloud platform, inform the device to stop, and the device will respond within one reporting interval in a good signal environment.



6. Report:

- ① When stopping record data, device will generate PDF report automatically.
Via USB cable connect with PC, can access it directly.
- ② On the Frigga cloud platform, the whole transportation data will be backed up, and can be viewed through device ID.

①



②



Report



Cautions

Please read the following notes carefully before using:

- When you find that the device didn't upload the data to cloud, Please confirm that the device is working properly or whether the device is in flight mode.
- Please confirm that the device is working in the range of measurement.
- Please maintain Frigga A90 in seal state. (Don't tear open the package).
- Don't use external force to impact the device.
- Don't take apart the device by yourself.
- Please keep the device away from fire.

Key Features



New experience of temperature logger
USB logger + Real-time cloud



Keeping all the usage habits of USB data logger



Full cold chain visibility (location, temperature, track routes)
via Frigga cloud




Improve transportation efficiency and reduce products
loss with real-time monitoring



24/7 data control & analysis, manage quality and control of your
products in-transit. Real time alert via SMS and email

Salute Extraordinary



Technical Support: support@dewav.com